

Help-Yourself Yarn Box

This easy-to-use yarn dispenser holds 5 spools of colorful yarn—25 yards in all! The box is specially designed to keep the yarn clean and tangle-free. Children simply pull out the color they want and cut off the length they need.

Setting Up the Yarn Box

The spools are already loaded in the box, so all you have to do is thread the ends of the yarn through the grommets in the front of the box. (**Note:** It's easier to push the yarn through the grommet if you wrap a piece of tape around the tip.)

Refill yarn spools are available from Lakeshore. (To order, visit our website or call the number below and ask for item number LL648.) To reload the box, see the back of this page.

(continued on back)

Refilling the Yarn Box

1. Open the box and remove the used spools and dowel by pushing the center spool away from the grommets while lifting the dowel up and out of the brackets. (Pull any remaining yarn back through the grommets if necessary.)
2. Slide the empty spools off of the dowel and replace them with full spools from the refill pack.
3. Position the dowel over the openings in the tops of the brackets and drop it in. The ends of the dowel should lock into place in the brackets.
4. Thread the yarn ends through the grommets, close the lid, and you're all set!